

RONDE INTALLATION GUIDE



IMPORTANT SAFETY INSTRUCTIONS

1. Read carefully before installing fixture. Retain for future reference.




To prevent electrical shock, turn off electricity at fuse box before proceeding.

- 2. Failure to follow instructions may result in serious injury or death.
- 3. Upon receipt the fixture, thoroughly inspect for any freight damage which should be brought to the attention of the delivery carrier. Compare the catalog description listed on the package slip with the fixture label on the housing to assure you have received material.
- 4. This fixture must be wired in accordance with the international electrical code and applicable local codes and ordinances. Proper grounding is required to insure personal safety. Carefully observe the correct grounding procedure under installation section.

MOUNTING POINT LOCATIONS- 14" AND 2' ROND

120° (3X) Hole Size: 7/32" Use #10 Anchor provided by other POWER LOCATION CENTER POINT OF FIXTURE

MOUNTING POINT LOCATIONS- ROND 3', 4', AND 5'



	14"	2'	3'	4'	5'
Ø	10-1/4"	18-3/4"	22"	32-1/2"	44-1/2"
Α	8-7/8"	16-7/32"	15-17/32"	23"	31-15/32"
В	5-1/8"	9-3/8"	7-49/64"	11-1/2"	15-47/64"