

# **LED WALL PACKS**

INSTALL INSTRUCTIONS




### **WARNING**

### PLEASE FIND A QUALIFIED ELECTRICIAN FOR INSTALLATION. Please read the instructions before you install and use the luminaire.


- To avoid electric shock, disconnect power at source prior to installation.
- The installation should be performed by qualified electricians or lighting technicians.
- · Before conducting any installation, maintenance, or removal, disable all power to the luminaries and wait until the fixture cool down.
- Do not touch the fixture while it is in service.
- If there is any problem with the fixture, D0 turn off power and D0 N0T attempt repair unless you are a qualified technician or the customer service member.
- The electrical rating of this product is 120-277V AC when no photocell. There are 120V and 277V version for this products when contains photocell. Please read the label information carefully to get proper input voltage for this product.
- Suitable for wet locations.

# **INSTALLATION**


#### 1. JUNCTION BOX MOUNTING




1. Loosen screws and remove the front lens set carefully from the back plate.




2. Drill appropriate knockouts (B) for wiring, the fixture supports standard 3 1/4" and 4"Junction box.



3. Attach the back plate on the wall, use the supplied gaskets for a weather tight seal.




4. Finish wiring (Black for Line, White for Neutral and Bare wire for Ground).




5. Replace the lens on the hinges, make connections and close the lens set then tighten the screws.

# 2. CONDUIT MOUNTING




- 1. Loosen screws and remove the front lens set carefully from the back plate. (See step 1 above)
- 2. Remove 1/2" plug from where you intend to feed conduit feeded.



- 3. Drilling out the holes (C) to secure it on the wall with choosing proper screws.

  4. Einich wiring ( black for line White for
- 4. Finish wiring ( black for line, White for neutral and green for ground). (See step 4 above)



5. Replace the lens set on the hinge and finish connection, Close the lens set and tighten the screws to fasten the lens set to the back plate.